

**Arcade Freestanding Paper Holder US-ARCA42**

**Arcade Freestanding Towel Holder US-ARCA43**

## Installation Instructions

Before beginning installation, check for any damage that may have occurred during transport.

**Note: Damage claims cannot be made during or after installation.**

### CLEANING INSTRUCTIONS

Rinse away any traces of soap and gently dry with a clean, soft cloth after each use. Rinse completely with water and dry any overspray. This will maintain the finish and avoid water spotting.

To remove mineral deposits, use a 50/50 solution of white vinegar and water. Do not allow the solution to soak on the product.

Simichrome Polish® contains a protective film to enhance maintenance and is helpful in preventing water spot buildup. Follow instructions to ensure optimum results.

Never use an abrasive material such as a brush or scouring pad to clean the surface. The use of abrasive cleaners, cleansers or disinfectants will alter the surface finish and void the warranty.

Do not allow certain materials such as toothpaste, cologne, shaving cream, nail polish remover, vinegar, wine, drain and glass cleaners to remain on the surface. Prolonged contact will alter surface finishes and void the warranty.

**We DO NOT recommend using any household cleaners as many can cause damage to the finish.**

Please see the website for care instructions for specific finishes.


**Warranty** - This **Crosswater London** product is covered by a limited lifetime warranty.

For full details, terms and conditions please visit our website.

For further information contact: **Crosswater London**, 393 Fortune Blvd., Milford, MA 01757


Toll free number: 844-XWATER-1 (844-992-8371) tel: 508-381-0433 fax: 508-381-6068

[www.crosswaterlondon.com](http://www.crosswaterlondon.com) email: [technical@crosswaterlondon.com](mailto:technical@crosswaterlondon.com)



Arcade Freestanding  
Paper Holder

US-ARCA42CHR  
US-ARCA42NKL




Arcade Freestanding  
Towel Holder

US-ARCA43CHR  
US-ARCA43NKL

## Arcade Freestanding Paper Holder

US-ARCA42CHR

US-ARCA42NKL



## Arcade Freestanding Towel Holder

US-ARCA43CHR

US-ARCA43NKL

