


## Installation Instructions



Arcade Paper Holder  
US-ARCA5




Arcade Towel Ring  
US-ARCA3




Arcade Wall-mount Soap Dispenser  
US-ARCA19




Arcade Single Robe Hook  
US-ARCA14




Arcade Double Robe Hook  
US-ARCA4



Arcade Toilet Brush Holder  
US-ARCA8



Arcade Corner Wall Basket  
US-ARCA22



Arcade Wall Basket  
US-ARCA23

**Warranty** - This **Crosswater London** product is covered by a limited lifetime warranty. For full details, terms and conditions please visit our website.

For further information contact: **Crosswater London**, 393 Fortune Blvd., Milford, MA 01757

[www.crosswaterlondon.com](http://www.crosswaterlondon.com)

Toll free number: 844-XWATER-1 (844-992-8371) tel: 508-381-0433 fax: 508-381-6068 email: [technical@crosswaterlondon.com](mailto:technical@crosswaterlondon.com)

# Please read these instructions carefully and keep in a safe place for future reference.

## CLEANING INSTRUCTIONS

Rinse away any traces of soap and gently dry with a clean, soft cloth after each use. Rinse completely with water and dry any overspray. This will maintain the finish and avoid water spotting.

To remove mineral deposits, use a 50/50 solution of white vinegar and water. Do not allow the solution to soak on the product.

Simichrome Polish® contains a protective film to enhance maintenance and is helpful in preventing water spot buildup. Follow instructions to ensure optimum results.

Never use an abrasive material such as a brush or scouring pad to clean the surface. The use of abrasive cleaners, cleansers or disinfectants will alter the surface finish and void the warranty.

Do not allow certain materials such as toothpaste, cologne, shaving cream, nail polish remover, vinegar, wine, drain and glass cleaners to remain on the surface. Prolonged contact will alter surface finishes and void the warranty.

**We DO NOT recommend using any household cleaners as many can cause damage to the finish.**

Please see the website for care instructions for specific finishes.


## INSTALLATION INSTRUCTIONS

The product should be installed by a professional, following the recommended installation instructions.


Please follow the diagrams to install the accessories onto the wall.

Tools required:


 Flat-head Screwdriver	 Pencil
 Drill with 6mm or 1/4" drill bit	 Hammer




Determine the final installation position, mark the mounting hole positions in pencil.




Using a 6mm or 1/4" drill bit, drill holes in the marked positions.



Insert the wall anchors into the drilled holes.



Use the flat-head screwdriver and the stainless steel screws to secure the base to the wall. Please ensure that the slot on the screw heads are horizontal.



Insert the basket body into the base. Tighten it using the allen key supplied.