


1000/1500/2000/2500/3000

Shower Valve Trim Kits

US-ARCV34/US-ARCV35 US-BL1000/1500/2000/2500/3000 US-PRO1000/1500/2000/2500/3000 US-WF1000/1500/2000/2500/3000 US-WP1000/1500/2000/2500/3000

Installation Instructions





Introduction

The installation must comply with all plumbing codes including local codes. **NOTE:** Image shows single-outlet trim kit, please follow the same steps if you have a multi-outlet valve.

NOTE: These instructions also apply if you have a lever or cross handle. (Please make sure you place in correct orientation if there are etchings on the front of the handle.)

INSTALLATION: Turn off the main water supply before connecting to any existing pipe work.


WARNING! Please check for any hidden pipes and cables, electric or otherwise before drilling holes in a wall.

NOTE: Inspect for any damage that may have occurred during transport. Damage claims cannot be made during or after installation.

Tools required











1 Installation 1000 rough

- Follow install guide for US-WLBP1000 valve rough.
- Attach collars by turning these into the valve.

1 Installation 1500 rough

- Follow install guide for US-WLBP1500 valve rough.
- Attach collars by turning these into the valve.





2 Installation

- Remove the adhesive tape film on the backside of cover plate.
- Apply a narrow bead of clear silicone adhesive caulk around the back edge of the cover plate and carefully press into position. (Please make sure you place in correct orientation if there are etchings on the front of the cover plate.)
- Fit the control handles by lining up the flat surface of the valve cover with the set screw on the handle, tighten the screw with an hexagonal key.
- The cover plate comes affixed with a removable cUPC sticker.
 The sticker may be peeled off following installation of the cover plate.

