

Darby Ha'g_ W5a` fda'S` V 6[hWfWdTrim 15-1)-T Installation Instructions





For ease of installation you will need:

- To read the installation instructions completely before beginning. that may have occurred during transport.
- To read all warnings, care, and maintenance information.
- To complete the valve rough-in prior to installing this trim kit.

Before beginning installation, check for any damage that may have occurred during transport. **Note: Damage claims cannot be made during or after installation.**









- If the handle will not engage the stem, then:
- a. Remove the handle and escutcheon assembly.

c. Reinstall the handle and escutcheon as in step #2.

d. If the escutcheon will not firmly secure to the wall please go to step #3.

b. Install the extended stem and nipple supplied with the trim.



Cleaning Instructions

Rinse away any traces of soap and gently dry with a clean, soft cloth after each use. Rinse completely with water and dry any overspray. This will maintain the finish and avoid water spotting.

To remove mineral deposits, use a 50/50 solution of white vinegar and water. Do not allow the solution to soak on the product. Simichrome Polish® contains a protective film to enhance maintenance and is helpful in preventing water spot buildup. Follow instructions to ensure optimum results.

Never use an abrasive material such as a brush or scouring pad to clean the surface. The use of abrasive cleaners, cleansers or disinfectants will alter the surface finish and void the warranty.

Do not allow certain materials such as toothpaste, cologne, shaving cream, nail polish remover, vinegar, wine, drain and glass cleaners to remain on the surface. Prolonged contact will alter surface finishes and void the warranty.

We DO NOT recommend using any household cleaners as many can cause damage to the finish.

Please see the website for care instructions for specific finishes.

Replacement Parts

NO.	Description	Part No.
1	Threaded Nipple	5T1C0319NT
2	Stem	5P0C0582NT



email: technical@crosswaterlondon.com

Applicable Standards/Codes

IAPMO certified to meet or exceed the following:

- ASME A112.18.1/CSA B125.1
- Uniform Plumbing Code
- National Plumbing Code of Canada

- LONDON -

ADA Compliant

Installation Dimensions



tel: 508-381-0433

fax: 508-381-6068

4



